




Performance Data

ROUND DAMPERS

STATIC PRESSURE DROP



Determining Static Pressure Drop (Round)

To determine static pressure drop through an open damper, start on the left side of the damper pressure drop chart. Given the CFM of air flow through the damper, follow the CFM line to the diagonal line of the damper size required, then down to the static pressure drop of the unit.

Example:

The pressure drop of an 8" damper with 700 CFM flow is .051 inches w.g.

Job Name:

Location:

Architect:

Engineer:

Contractor:



BADR and ASFOUR
Engineering & Metal Industries

BADR AND ASFOUR
For Engineering and metal industries.
Free zone, Matahara, New Menya, Egypt
Email address: sales.support@badr-asfour.com
W: www.cvshvac.com | badr-asfour.com